

# Tutorials 4.4 Frames

De Wiki

Aller à : [navigation](#), [rechercher](#)

[Spécial:Livre](#) > [Discussion utilisateur:52.14.221.113](#) > [Spécial:Liste des fichiers/18.204.214.205](#) > [LoadingSunEphemeris 4.4](#) > [Tutorials 4.4 Frames](#)

## What is a frame ?

As for the time scale (see previous tutorial), the easiest way to create a frame is to use the associated factory (`FramesFactory.getXXX()`).

Thanks to its factory, this frame will be unique in all the rest of your code.

**Code example:** [create frames](#)

## How to configure it

Transformations between frames may be configured thanks to a certain modelization level (taking into account polar motion, tides, ...).

In the following example, via the `getSimplifiedConfiguration()` method, we will be able to customize such transformations.

Note that if we take into account all modelizations, **CPU** time will be affected each time frames transformations will be used (i.e. very often for numerical orbit propagations).

**Code example:** [configure frames](#)

Récupérée de « [http://patrius.cnes.fr/index.php?title=Tutorials\\_4.4\\_Frames&oldid=2476](http://patrius.cnes.fr/index.php?title=Tutorials_4.4_Frames&oldid=2476) »

Catégorie :

- [Tutorials 4.4](#)

## Menu de navigation

### Outils personnels

- [13.58.39.129](#)
- [Discussion avec cette adresse IP](#)
- [Créer un compte](#)
- [Se connecter](#)

### Espaces de noms

- [Page](#)
- [Discussion](#)

## **Variantes**

### **Affichages**

- [Lire](#)
- [Voir le texte source](#)
- [Historique](#)
- [Exporter en PDF](#)

### **Plus**

### **Rechercher**

  

## **PATRIUS**

- [Welcome](#)

### **Evolutions**

- [Main differences between V4.13 and V4.12](#)
- [Main differences between V4.12 and V4.11](#)
- [Main differences between V4.11 and V4.10](#)
- [Main differences between V4.10 and V4.9](#)
- [Main differences between V4.9 and V4.8](#)
- [Main differences between V4.8 and V4.7](#)
- [Main differences between V4.7 and V4.6.1](#)
- [Main differences between V4.6.1 and V4.5.1](#)
- [Main differences between V4.5.1 and V4.4](#)
- [Main differences between V4.4 and V4.3](#)
- [Main differences between V4.3 and V4.2](#)
- [Main differences between V4.2 and V4.1.1](#)
- [Main differences between V4.1.1 and V4.1](#)
- [Main differences between V4.1 and V4.0](#)
- [Main differences between V4.0 and V3.4.1](#)

### **User Manual**

- [User Manual 4.13](#)
- [User Manual 4.12](#)
- [User Manual 4.11](#)

- [User Manual 4.10](#)
- [User Manual 4.9](#)
- [User Manual 4.8](#)
- [User Manual 4.7](#)
- [User Manual 4.6.1](#)
- [User Manual 4.5.1](#)
- [User Manual 4.4](#)
- [User Manual 4.3](#)
- [User Manual 4.2](#)
- [User Manual 4.1](#)
- [User Manual 4.0](#)
- [User Manual 3.4.1](#)
- [User Manual 3.3](#)

## Tutorials

- [Tutorials 4.5.1](#)
- [Tutorials 4.4](#)
- [Tutorials 4.1](#)
- [Tutorials 4.0](#)

## Links

- [CNES freeware server](#)

## Navigation

- [Accueil](#)
- [Modifications récentes](#)
- [Page au hasard](#)
- [Aide](#)

## Outils

- [Pages liées](#)
- [Suivi des pages liées](#)
- [Pages spéciales](#)
- [Adresse de cette version](#)
- [Information sur la page](#)
- [Citer cette page](#)

• Dernière modification de cette page le 3 octobre 2019 à 12:06.

- [Politique de confidentialité](#)
- [À propos de Wiki](#)
- [Avertissements](#)
-

