

SequenceOfAttitudes 4.1

De Wiki

Aller à : [navigation](#), [rechercher](#)
[SequenceOfAttitudes 4.1](#)

```
public class SequenceOfAttitudeLaws {  
  
    public static void main(String[] args) throws PatriusException {  
  
        // Patrius Dataset initialization (needed for example to get the UTC  
time  
        PatriusDataset.addResourcesFromPatriusDataset() ;  
  
        // Recovery of the UTC time scale using a "factory" (not to duplicate  
such unique object)  
        final TimeScale TUC = TimeScalesFactory.getUTC();  
  
        // Date of the orbit given in UTC time scale)  
        final AbsoluteDate iniDate = new AbsoluteDate("2010-01-  
01T12:00:00.000", TUC);  
  
        // Getting the frame with wich will defined the orbit parameters  
        // As for time scale, we will use also a "factory".  
        final Frame GCRF = FramesFactory.getGCRF();  
  
        // Initial orbit  
        final double sma = 7200.e+3;  
        final double exc = 0.01;  
        final double inc = FastMath.toRadians(98.);  
        final double pa = FastMath.toRadians(0.);  
        final double raan = FastMath.toRadians(90.);  
        final double anm = FastMath.toRadians(0.);  
        final double MU = Constants.WGS84_EARTH_MU;  
  
        final KeplerianParameters par = new KeplerianParameters(sma, exc,  
inc, pa, raan, anm, PositionAngle.MEAN, MU);  
        final Orbit iniOrbit = new KeplerianOrbit(par, GCRF, iniDate);  
  
        // Using the Meeus model for the Sun.  
        final CelestialBody sun = new MeeusSun();  
        final double sunRadius = Constants.SUN_RADIUS;  
  
        // Definition of the Earth ellipsoid for later atmospheric density  
computation  
        final Frame ITRF = FramesFactory.getITRF();  
        final double earthRadius = Constants.WGS84_EARTH_EQUATORIAL_RADIUS;  
        final GeometricBodyShape earth = new  
ExtendedOneAxisEllipsoid(earthRadius, Constants.WGS84_EARTH_FLATTENING, ITRF,  
"EARTH");  
    }  
}
```

```

// Initializing attitude sequence
final AttitudesSequence seqAtt = new AttitudesSequence();

// Building a first attitude law (Sun pointing)
final Vector3D firstAxis = new Vector3D(1., 0., 0.);
final Vector3D secondAxis = new Vector3D(0., 1., 0.);
final AttitudeLaw sunPointingLaw = new SunPointing(sun, firstAxis,
secondAxis, sun);

// Building a second attitude law (LVLH)
final AttitudeLaw lvlhLaw = new LofOffset(LOFType.LVLH);

// Events that will switch from a law to another
final double maxCheck = 10.;
final double threshold = 1.e-3;
final EventDetector eventEntryEclipse = new EclipseDetector(sun,
sunRadius, earth, earthRadius, 0,
maxCheck, threshold, Action.RESET_STATE, Action.RESET_STATE);
final EventDetector eventExitEclipse = new EclipseDetector(sun,
sunRadius, earth, earthRadius, 0,
maxCheck, threshold, Action.RESET_STATE, Action.RESET_STATE);

//Adding switches
seqAtt.addSwitchingCondition(lvlhLaw, eventEntryEclipse, true, false,
sunPointingLaw);
seqAtt.addSwitchingCondition(sunPointingLaw, eventExitEclipse, false,
true, lvlhLaw);
}
}

```

If you want to check some results seeing attitude values along the propagation, you may call, for example, this method:

```

public static void testByPropagation ( final Orbit iniOrbit, final
AttitudesSequence seqAtt, final CelestialBody sun ) throws PatriusException {

// We create a spacecraft state
final SpacecraftState iniState = new SpacecraftState(iniOrbit);

// Initialization of the Runge Kutta integrator with a 2 s step
final double pasRk = 2.;
final FirstOrderIntegrator integrator = new
ClassicalRungeKuttaIntegrator(pasRk);

// Initialization of the propagator
final NumericalPropagator propagator = new
NumericalPropagator(integrator);
propagator.resetInitialState(iniState);

```

```

// Forcing integration using cartesian equations
propagator.setOrbitType(OrbitType.CARTESIAN);

// Adding the attitude sequence
propagator.setAttitudeProvider(seqAtt);
seqAtt.registerSwitchEvents(propagator);

// Loop every 10 mn ...
final double step = 600.;
final double epsilon = 1.e-12;
for (int i = 1; i <= 20; i++) {

    AbsoluteDate date = iniOrbit.getDate().shiftedBy(i*step);

    final SpacecraftState state = propagator.propagate(date);

    // Attitude in LVLH
    final Attitude attLVLH = state.getAttitude(LOFType.LVLH);
    final double psiLVLH =
attLVLH.getRotation().getAngles(RotationOrder.ZYX)[0];
    final double tetaLVLH =
attLVLH.getRotation().getAngles(RotationOrder.ZYX)[1];

    // Attitude in GCRF
    final Attitude attGCRF = state.getAttitude();
    final double psiGCRF =
attGCRF.getRotation().getAngles(RotationOrder.ZYX)[0];
    final double tetaGCRF =
attGCRF.getRotation().getAngles(RotationOrder.ZYX)[1];

    // Direction of the Sun from the cdg of the satellite
    final Vector3D sunPos = sun.getPVCoordinates(date,
FramesFactory.getGCRF()).getPosition();
    final Vector3D satPos = state.getPVCoordinates().getPosition();
    final Rotation sunDir = new Rotation(Vector3D.PLUS_I,
sunPos.subtract(satPos));

    // Sun direction
    final double psiSun = sunDir.getAngles(RotationOrder.ZYX)[0];
    final double tetaSun = sunDir.getAngles(RotationOrder.ZYX)[1];

    if ( (FastMath.abs(psiLVLH) < epsilon) || (FastMath.abs(tetaLVLH)
< epsilon) ) {
        System.out.println(date+" => LVLH mode");
    } else {
        System.out.println(date+" => Sun pointing mode");
        System.out.println("    Delta Psi =
"+FastMath.toDegrees(psiSun-psiGCRF)+" deg");
        System.out.println("    Delta Teta =
"+FastMath.toDegrees(tetaSun-tetaGCRF)+" deg");
    }
}

```

}

}

Récupérée de « http://patrius.cnes.fr/index.php?title=SequenceOfAttitudes_4.1&oldid=1829 »

Menu de navigation

Outils personnels

- [3.141.29.162](#)
- [Discussion avec cette adresse IP](#)
- [Créer un compte](#)
- [Se connecter](#)

Espaces de noms

- [Page](#)
- [Discussion](#)

Variantes

Affichages

- [Lire](#)
- [Voir le texte source](#)
- [Historique](#)
- [Exporter en PDF](#)

Plus

Rechercher

PATRIUS

- [Welcome](#)

Evolutions

- [Main differences between V4.15 and V4.14](#)

- [Main differences between V4.14 and V4.13](#)
- [Main differences between V4.13 and V4.12](#)
- [Main differences between V4.12 and V4.11](#)
- [Main differences between V4.11 and V4.10](#)
- [Main differences between V4.10 and V4.9](#)
- [Main differences between V4.9 and V4.8](#)
- [Main differences between V4.8 and V4.7](#)
- [Main differences between V4.7 and V4.6.1](#)
- [Main differences between V4.6.1 and V4.5.1](#)
- [Main differences between V4.5.1 and V4.4](#)
- [Main differences between V4.4 and V4.3](#)
- [Main differences between V4.3 and V4.2](#)
- [Main differences between V4.2 and V4.1.1](#)
- [Main differences between V4.1.1 and V4.1](#)
- [Main differences between V4.1 and V4.0](#)
- [Main differences between V4.0 and V3.4.1](#)

User Manual

- [User Manual 4.15](#)
- [User Manual 4.14](#)
- [User Manual 4.13](#)
- [User Manual 4.12](#)
- [User Manual 4.11](#)
- [User Manual 4.10](#)
- [User Manual 4.9](#)
- [User Manual 4.8](#)
- [User Manual 4.7](#)
- [User Manual 4.6.1](#)
- [User Manual 4.5.1](#)
- [User Manual 4.4](#)
- [User Manual 4.3](#)
- [User Manual 4.2](#)
- [User Manual 4.1](#)
- [User Manual 4.0](#)
- [User Manual 3.4.1](#)
- [User Manual 3.3](#)

Tutorials

- [Tutorials 4.15](#)
- [Tutorials 4.14](#)
- [Tutorials 4.13.5](#)
- [Tutorials 4.12.1](#)
- [Tutorials 4.8.1](#)
- [Tutorials 4.5.1](#)
- [Tutorials 4.4](#)
- [Tutorials 4.1](#)
- [Tutorials 4.0](#)

Links

- [CNES freeware server](#)

Navigation

- [Accueil](#)
- [Modifications récentes](#)
- [Page au hasard](#)
- [Aide](#)

Outils

- [Pages liées](#)
- [Suivi des pages liées](#)
- [Pages spéciales](#)
- [Adresse de cette version](#)
- [Information sur la page](#)
- [Citer cette page](#)

• Dernière modification de cette page le 18 décembre 2018 à 10:19.

- [Politique de confidentialité](#)
- [À propos de Wiki](#)
- [Avertissements](#)

- 