

Tutorials 4.1 Frames

De Wiki

Aller à : [navigation](#), [rechercher](#)

[Tutorials 4.1 Frames](#)

What is a frame ?

As for the time scale (see previous tutorial), the easiest way to create a frame is to use the associated factory (`FramesFactory.getXXX()`).

Thanks to its factory, this frame will be unique in all the rest of your code.

Code example: [create frames](#)

How to configure it

Transformations between frames may be configured thanks to a certain modelization level (taking into account polar motion, tides, ...).

In the following example, via the `getSimplifiedConfiguration()` method, we will be able to customize such transformations.

Note that if we take into account all modelizations, **CPU** time will be affected each time frames transformations will be used (i.e. very often for numerical orbit propagations).

Code example: [configure frames](#)

Récupérée de « http://patrius.cnes.fr/index.php?title=Tutorials_4.1_Frames&oldid=1885 »

[Catégorie](#) :

- [Tutorials 4.1](#)

Menu de navigation

Outils personnels

- [18.218.73.233](#)
- [Discussion avec cette adresse IP](#)
- [Créer un compte](#)
- [Se connecter](#)

Espaces de noms

- [Page](#)
- [Discussion](#)

Variantes

Affichages

- [Lire](#)
- [Voir le texte source](#)
- [Historique](#)
- [Exporter en PDF](#)

Plus

Rechercher

PATRIUS

- [Welcome](#)

Evolutions

- [Main differences between V4.15 and V4.14](#)
- [Main differences between V4.14 and V4.13](#)
- [Main differences between V4.13 and V4.12](#)
- [Main differences between V4.12 and V4.11](#)
- [Main differences between V4.11 and V4.10](#)
- [Main differences between V4.10 and V4.9](#)
- [Main differences between V4.9 and V4.8](#)
- [Main differences between V4.8 and V4.7](#)
- [Main differences between V4.7 and V4.6.1](#)
- [Main differences between V4.6.1 and V4.5.1](#)
- [Main differences between V4.5.1 and V4.4](#)
- [Main differences between V4.4 and V4.3](#)
- [Main differences between V4.3 and V4.2](#)
- [Main differences between V4.2 and V4.1.1](#)
- [Main differences between V4.1.1 and V4.1](#)
- [Main differences between V4.1 and V4.0](#)
- [Main differences between V4.0 and V3.4.1](#)

User Manual

- [User Manual 4.15](#)

- [User Manual 4.14](#)
- [User Manual 4.13](#)
- [User Manual 4.12](#)
- [User Manual 4.11](#)
- [User Manual 4.10](#)
- [User Manual 4.9](#)
- [User Manual 4.8](#)
- [User Manual 4.7](#)
- [User Manual 4.6.1](#)
- [User Manual 4.5.1](#)
- [User Manual 4.4](#)
- [User Manual 4.3](#)
- [User Manual 4.2](#)
- [User Manual 4.1](#)
- [User Manual 4.0](#)
- [User Manual 3.4.1](#)
- [User Manual 3.3](#)

Tutorials

- [Tutorials 4.15](#)
- [Tutorials 4.14](#)
- [Tutorials 4.13.5](#)
- [Tutorials 4.12.1](#)
- [Tutorials 4.8.1](#)
- [Tutorials 4.5.1](#)
- [Tutorials 4.4](#)
- [Tutorials 4.1](#)
- [Tutorials 4.0](#)

Links

- [CNES freeware server](#)

Navigation

- [Accueil](#)
- [Modifications récentes](#)
- [Page au hasard](#)
- [Aide](#)

Outils

- [Pages liées](#)
- [Suivi des pages liées](#)
- [Pages spéciales](#)
- [Adresse de cette version](#)

- [Information sur la page](#)

- [Citer cette page](#)

- Dernière modification de cette page le 20 décembre 2018 à 15:39.

- [Politique de confidentialité](#)

- [À propos de Wiki](#)

- [Avertissements](#)

- 