

User Manual 4.7 Orbital parameters

De Wiki

Aller à : [navigation](#), [rechercher](#)

[User Manual 4.7 Orbital parameters](#)

Introduction

Scope

The "Orbital parameters" package contains classes to represent the orbital state of a space object. Several types of parameters are available (cartesian, keplerian, equinoctial... with different position angle definitions : true, mean, eccentric). Orbital parameters do not define a date nor a frame. To fully define an orbit, including date and frame, please refer to [FDY_Orbits_Home Orbits].

Javadoc

The classes for orbital parameters description are available in the package `fr.cnes.sirius.patrius.orbits.orbitalparameters`.

Library

Javadoc

Patrius [Package fr.cnes.sirius.patrius.orbits.orbitalparameters](#)

Links

None as of now.

Useful Documents

None as of now.

Package Overview

All different orbital parameters types extend the abstract class `AbstractOrbitalParameters` and implement the interface `IOrbitalParameters` (the following class package may not contain all classes extending `AbstractOrbitalParameters` class).



All conversions methods from one type to another are specifically handled by each type of orbital parameters, thus optimising conversions.

Features Description

Available parameters

The available parameters types are :

- Cartesian : X, Y, Z, Vx, Vy, Vz
- Keplerian : a, e, i, perigee argument, right ascension of ascending node, anomaly (in each position angle types)

- Equinoctial : a, ex, ey (eccentricity vector), hx, hy (inclination vector), longitude argument (in each position angle types)
- Alternate equinoctial : n (mean motion), ex, ey (eccentricity vector), hx, hy (inclination vector), longitude argument (in each position angle types but stored in mean)
- Stela Equinoctial : a, ex, ey (eccentricity vector), ix, iy (inclination vector), mean longitude argument
- Circular : a, ex, ey (eccentricity vector), i, right ascension of ascending node, latitude argument (in each position angle types)
- Apsis (using radius) : periapsis, apoapsis, i, perigee argument, right ascension of ascending node, anomaly (in each position angle types)
- Apsis (using altitude) : altitude of periapsis, altitude of apoapsis, i, perigee argument, right ascension of ascending node, anomaly (in each position angle types)
- Equatorial : a, e, longitude of the periapsis ($\omega + \Omega$), ix (first component of inclination vector), iy (second component of inclination vector), anomaly (in each position angle types)
- Reentry : altitude, latitude, longitude, velocity norm, slope of velocity, azimuth of velocity

Getting Started

Any orbital parameters can be defined using the chosen constructor. Here is an example using circular parameters and true anomaly:

```
final CircularParameters circularParameters = new CircularParameters(10000E3,
0.1, 0.2, 0.3, 0.4, 0.5, PositionAngle.TRUE, Constants.EGM96_EARTH_MU);
```

Then conversions to any orbital parameters type can directly be obtained using the conversion routines. Here is an example of conversion to equinoctial parameters:

```
final EquinoctialParameters equinoctialParameters = circularParameters
.getEquinoctialParameters();
```

Contents

Interfaces

None as of now.

Classes

Class	Summary	Javadoc
CartesianParameters	Cartesian parameters object.	...
KeplerianParameters	Keplerian parameters object.	...
CircularParameters	Circular parameters object.	...
EquinoctialParameters	Equinoctial parameters object.	...
AlternateEquinoctialParameters	Alternate Equinoctial parameters object.	...
StelaEquinoctialParameters	Stela equinoctial parameters object.	...
EquatorialParameters	Equatorial parameters object.	...
ApsisRadiusParameters	Apsis parameters object (using radius).	...

ApsisAltitudeParameters	Apsis parameters object (using altitude). ...
ReentryParameters	Reentry parameters object. ...
Récupérée de	
« http://patrius.cnes.fr/index.php?title=User_Manual_4.7_Orbital_parameters&oldid=2909 »	
Catégorie :	
• User Manual 4.7 Flight Dynamics	

Menu de navigation

Outils personnels

- [18.189.180.43](#)
- [Discussion avec cette adresse IP](#)
- [Créer un compte](#)
- [Se connecter](#)

Espaces de noms

- [Page](#)
- [Discussion](#)

Variantes

Affichages

- [Lire](#)
- [Voir le texte source](#)
- [Historique](#)
- [Exporter en PDF](#)

Plus

Rechercher

PATRIUS

- [Welcome](#)

Evolutions

- [Main differences between V4.14 and V4.13](#)
- [Main differences between V4.13 and V4.12](#)
- [Main differences between V4.12 and V4.11](#)
- [Main differences between V4.11 and V4.10](#)
- [Main differences between V4.10 and V4.9](#)
- [Main differences between V4.9 and V4.8](#)
- [Main differences between V4.8 and V4.7](#)
- [Main differences between V4.7 and V4.6.1](#)
- [Main differences between V4.6.1 and V4.5.1](#)
- [Main differences between V4.5.1 and V4.4](#)
- [Main differences between V4.4 and V4.3](#)
- [Main differences between V4.3 and V4.2](#)
- [Main differences between V4.2 and V4.1.1](#)
- [Main differences between V4.1.1 and V4.1](#)
- [Main differences between V4.1 and V4.0](#)
- [Main differences between V4.0 and V3.4.1](#)

User Manual

- [User Manual 4.14](#)
- [User Manual 4.13](#)
- [User Manual 4.12](#)
- [User Manual 4.11](#)
- [User Manual 4.10](#)
- [User Manual 4.9](#)
- [User Manual 4.8](#)
- [User Manual 4.7](#)
- [User Manual 4.6.1](#)
- [User Manual 4.5.1](#)
- [User Manual 4.4](#)
- [User Manual 4.3](#)
- [User Manual 4.2](#)
- [User Manual 4.1](#)
- [User Manual 4.0](#)
- [User Manual 3.4.1](#)
- [User Manual 3.3](#)

Tutorials

- [Tutorials 4.14](#)
- [Tutorials 4.13.5](#)
- [Tutorials 4.12.1](#)
- [Tutorials 4.8.1](#)
- [Tutorials 4.5.1](#)
- [Tutorials 4.4](#)
- [Tutorials 4.1](#)
- [Tutorials 4.0](#)

Links

- [CNES freeware server](#)

Navigation

- [Accueil](#)
- [Modifications récentes](#)
- [Page au hasard](#)
- [Aide](#)

Outils

- [Pages liées](#)
- [Suivi des pages liées](#)
- [Pages spéciales](#)
- [Adresse de cette version](#)
- [Information sur la page](#)
- [Citer cette page](#)
- Dernière modification de cette page le 7 mai 2021 à 07:27.
- [Politique de confidentialité](#)
- [À propos de Wiki](#)
- [Avertissements](#)
-