

# User Manual 4.4 Attitude Profile

De Wiki

Aller à : [navigation](#), [rechercher](#)  
[User Manual 4.4 Attitude Profile](#)

## Introduction

### Scope

An attitude profile is an attitude law providing the computation of an instantaneous attitude without any reference to the satellite orbit, nor to its attitude laws sequence. The purpose of this section is to present the attitude profiles available through the Patrius library.

### Javadoc

The guidance models and classes are available in the attitude profiles package in the Patrius library.

#### Library

#### Javadoc

Patrius [Package fr.cnes.sirius.patrius.attitudes/profiles](#)

### Links

None as of now.

### Useful Documents

None as of now.

### Package Overview

## Features Description

PATRIUS handles four different guidance profiles types:

- Profile expressed as quaternions represented as polynomials: `QuaternionPolynomialProfile`
- Profile expressed as quaternions represented as harmonics: `QuaternionHarmonicProfile`
- Profile expressed as angular velocities represented as polynomials:  
`AngularVelocitiesPolynomialProfile`
- Profile expressed as angular velocities represented as harmonics:  
`AngularVelocitiesHarmonicProfile`

### Harmonic guidance profiles

The functions representing the angular velocity of the satellite and the quaternion (or the Euler angles) expressing its orientation can be represented by an harmonic profile. The harmonic profile is a [MAT\_TPOL\_Home#HFourierSeries Fourier decomposition] of a periodic function:

$$S_n\left(f(x)\right) = a_0(f) + \sum_{k=1}^n \left( a_k(f) \cos\left(k x \left\{ \frac{2\pi}{T} \right\} \right) + b_k(f) \sin\left(k x \left\{ \frac{2\pi}{T} \right\} \right) \right) [/math>$$

The period T is generally computed knowing the nodes crossing periods.

The Fourier coefficients ( $n > 0$ ) of  $f(t)$  (the angular velocity / quaternions / Euler angles function) are given by :

$$a_0(f) = \frac{1}{T} \int_{-T/2}^{T/2} f(t) dt$$

$$b_0(f) = 0$$

$$a_n(f) = \frac{2}{T} \int_{-T/2}^{T/2} f(t) \cos\left(n t \frac{2\pi}{T}\right) dt$$

$$b_n(f) = \frac{2}{T} \int_{-T/2}^{T/2} f(t) \sin\left(n t \frac{2\pi}{T}\right) dt$$

## Polynomial guidance profiles

A polynomial guidance profile is generally composed by several segments (a segment corresponds to a time interval). Each segment contains the coefficients for the computation of a polynomial law representing the quaternion (or the Euler angles), or the angular velocity of the satellite; this polynomial law is valid only inside the time interval associated to the segment.

For a quaternion, the polynomials are defined as :

$$Qc_k(t) = \begin{pmatrix} \sum_{i=0}^n a_{0_i}_k \left(\frac{t-t_k}{\Delta t}\right) \\ \sum_{i=0}^n a_{1_i}_k \left(\frac{t-t_k}{\Delta t}\right) \\ \sum_{i=0}^n a_{2_i}_k \left(\frac{t-t_k}{\Delta t}\right) \\ \sum_{i=0}^n a_{3_i}_k \left(\frac{t-t_k}{\Delta t}\right) \end{pmatrix}$$

And for the angular velocity :

$$\Omega c_k(t) = \begin{pmatrix} \sum_{i=0}^n a_{x_i}_k \left(\frac{t-t_k}{\Delta t}\right) \\ \sum_{i=0}^n a_{y_i}_k \left(\frac{t-t_k}{\Delta t}\right) \\ \sum_{i=0}^n a_{z_i}_k \left(\frac{t-t_k}{\Delta t}\right) \end{pmatrix}$$

## Getting Started

### Build an harmonic profile from an attitude law

Given :

- the profile start date `origin`,
- the frame of expression `frame`,
- the Fourier series for each quaternion `q0`, `q1`, `q2` and `q3`,
- the profile time boundaries `timeInterval`,

one can build an angular velocities guidance profile using the code snippet below :

```
profile = new QuaternionHarmonicProfile(origin, frame, q0, q1, q2, q3,
timeInterval);
```

# Contents

## Interfaces

Interface	Summary	Javadoc
<b>AttitudeProfile</b>	Interface for all attitude profiles.	...

## Classes

Class	Summary	Javadoc
<b>QuaternionHarmonicProfile</b>	Object representing a quaternion guidance profile, calculated with Fourier series.	...
<b>QuaternionPolynomialProfile</b>	Object representing a quaternion guidance profile, calculated with polynomials.	...
<b>QuaternionPolynomialSegment</b>	Object representing a quaternion polynomial guidance profile on a segment.	...
<b>AngularVelocitiesHarmonicProfile</b>	Represents an angular velocities guidance profile, calculated with Fourier series.	...
<b>AngularVelocitiesPolynomialProfile</b>	Represents an angular velocities guidance profile, calculated with polynomial functions.	...
<b>AngularVelocitiesPolynomialProfileLeg</b>	Object representing an angular velocity polynomial guidance profile on a segment.	...

Récupérée de

« [http://patrius.cnes.fr/index.php?title=User\\_Manual\\_4.4\\_Attitude\\_Profile&oldid=2443](http://patrius.cnes.fr/index.php?title=User_Manual_4.4_Attitude_Profile&oldid=2443) »

Catégorie :

- [User Manual 4.4 Attitude](#)

## Menu de navigation

### Outils personnels

- [3.17.181.122](#)
- [Discussion avec cette adresse IP](#)
- [Créer un compte](#)
- [Se connecter](#)

### Espaces de noms

- [Page](#)
- [Discussion](#)

### Variantes

## Affichages

- [Lire](#)
- [Voir le texte source](#)
- [Historique](#)
- [Exporter en PDF](#)

## Plus

## Rechercher

## PATRIUS

- [Welcome](#)

## Evolutions

- [Main differences between V4.15 and V4.14](#)
- [Main differences between V4.14 and V4.13](#)
- [Main differences between V4.13 and V4.12](#)
- [Main differences between V4.12 and V4.11](#)
- [Main differences between V4.11 and V4.10](#)
- [Main differences between V4.10 and V4.9](#)
- [Main differences between V4.9 and V4.8](#)
- [Main differences between V4.8 and V4.7](#)
- [Main differences between V4.7 and V4.6.1](#)
- [Main differences between V4.6.1 and V4.5.1](#)
- [Main differences between V4.5.1 and V4.4](#)
- [Main differences between V4.4 and V4.3](#)
- [Main differences between V4.3 and V4.2](#)
- [Main differences between V4.2 and V4.1.1](#)
- [Main differences between V4.1.1 and V4.1](#)
- [Main differences between V4.1 and V4.0](#)
- [Main differences between V4.0 and V3.4.1](#)

## User Manual

- [User Manual 4.15](#)
- [User Manual 4.14](#)
- [User Manual 4.13](#)
- [User Manual 4.12](#)
- [User Manual 4.11](#)

- [User Manual 4.10](#)
- [User Manual 4.9](#)
- [User Manual 4.8](#)
- [User Manual 4.7](#)
- [User Manual 4.6.1](#)
- [User Manual 4.5.1](#)
- [User Manual 4.4](#)
- [User Manual 4.3](#)
- [User Manual 4.2](#)
- [User Manual 4.1](#)
- [User Manual 4.0](#)
- [User Manual 3.4.1](#)
- [User Manual 3.3](#)

## Tutorials

- [Tutorials 4.15](#)
- [Tutorials 4.14](#)
- [Tutorials 4.13.5](#)
- [Tutorials 4.12.1](#)
- [Tutorials 4.8.1](#)
- [Tutorials 4.5.1](#)
- [Tutorials 4.4](#)
- [Tutorials 4.1](#)
- [Tutorials 4.0](#)

## Links

- [CNES freeware server](#)

## Navigation

- [Accueil](#)
- [Modifications récentes](#)
- [Page au hasard](#)
- [Aide](#)

## Outils

- [Pages liées](#)
- [Suivi des pages liées](#)
- [Pages spéciales](#)
- [Adresse de cette version](#)
- [Information sur la page](#)
- [Citer cette page](#)

- Dernière modification de cette page le 29 août 2019 à 09:49.

- [Politique de confidentialité](#)
- [À propos de Wiki](#)
- [Avertissements](#)
- 