

User Manual 3.4.1 Orbital parameters

De Wiki

Aller à : [navigation](#), [rechercher](#)

[Utilisateur:18.221.112.220](#) > [Discussion utilisateur:3.16.70.101](#) > [Spécial:Pages liées/User Manual](#)
[3.4.1 Orbital parameters](#) > [Discussion utilisateur:18.222.239.77](#) > [User Manual 3.4.1 Orbital parameters](#)

Sommaire

- [1 Introduction](#)
 - [1.1 Scope](#)
 - [1.2 Javadoc](#)
 - [1.3 Links](#)
 - [1.4 Useful Documents](#)
 - [1.5 Package Overview](#)
- [2 Features Description](#)
 - [2.1 Available parameters](#)
- [3 Getting Started](#)
- [4 Contents](#)
 - [4.1 Classes](#)

Introduction

Scope

The "Orbital parameters" package contains classes to represent the orbital state of a space object. Several types of parameters are available (cartesian, keplerian, equinoctial... with different position angle definitions : true, mean, eccentric). Orbital parameters do not define a date nor a frame. To fully define an orbit, including date and frame, please refer to [Orbits](#).

Javadoc

The classes for orbital parameters description are available in the package `org.orekit.orbits.orbitalparameters` of OREKIT.

Library	Javadoc
Orekit	Package org.orekit.orbits.orbitalparameters

Links

None as of now.

Useful Documents

None as of now.

Package Overview

All different orbital parameters types extend the abstract class AbstractOrbitalParameters and implement the interface IOrbitalParameters.



All conversions methods from one type to another are specifically handled by each type of orbital parameters, thus optimising conversions.

Features Description

Available parameters

The available parameters types are :

- Cartesian : X, Y, Z, Vx, Vy, Vz
- Keplerian : a, e, i, perigee argument, right ascension of ascending node, anomaly (in each position angle types)
- Equinoctial : a, ex, ey (eccentricity vector), hx, hy (inclination vector), longitude argument (in each position angle types)
- Stela Equinoctial : a, ex, ey (eccentricity vector), ix, iy (inclination vector), mean longitude argument
- Circular : a, ex, ey (eccentricity vector), i, right ascension of ascending node, latitude argument (in each position angle types)
- Apsis (using radius) : periapsis, apoapsis, i, perigee argument, right ascension of ascending node, anomaly (in each position angle types)
- Apsis (using altitude) : altitude of periapsis, altitude of apoapsis, i, perigee argument, right ascension of ascending node, anomaly (in each position angle types)
- Equatorial : a, e, longitude of the periapsis ($\omega + \Omega$), ix (first component of inclination vector), iy (second component of inclination vector), anomaly (in each position angle types)
- Reentry : altitude, latitude, longitude, velocity norm, slope of velocity, azimuth of velocity

Getting Started

Any orbital parameters can be defined using the chosen constructor. Here is an example using circular parameters and true anomaly:

```
final CircularParameters circularParameters = new CircularParameters(10000E3,  
0.1, 0.2, 0.3, 0.4, 0.5, PositionAngle.TRUE, Constants.EGM96_EARTH_MU);
```

Then conversions to any orbital parameters type can directly be obtained using the conversion routines. Here is an example of conversion to equinoctial parameters:

```
final EquinoctialParameters equinoctialParameters = circularParameters  
.getEquinoctialParameters();
```

Contents

Classes

Class	Summary	Javadoc
CartesianParameters	Cartesian parameters object.	...
KeplerianParameters	Keplerian parameters object.	...
CircularParameters	Circular parameters object.	...
EquinoctialParameters	Equinoctial parameters object.	...
StelaEquinoctialParameters	Stela equinoctial parameters object.	...
EquatorialParameters	Equatorial parameters object.	...
ApsisRadiusParameters	Apsis parameters object (using radius).	...
ApsisAltitudeParameters	Apsis parameters object (using altitude).	...
ReentryParameters	Reentry parameters object.	...

Récupérée de
« http://patrius.cnes.fr/index.php?title=User_Manual_3.4.1_Orbital_parameters&oldid=1393 »

Catégorie :

- [User Manual 3.4.1 Flight Dynamics](#)

Menu de navigation

Outils personnels

- [3.146.255.113](#)
- [Discussion avec cette adresse IP](#)
- [Créer un compte](#)
- [Se connecter](#)

Espaces de noms

- [Page](#)
- [Discussion](#)

Variantes

Affichages

- [Lire](#)
- [Voir le texte source](#)
- [Historique](#)
- [Exporter en PDF](#)

Plus

Rechercher

	Rechercher	Lire
--	------------	------

PATRIUS

- [Welcome](#)

Evolutions

- [Main differences between V4.13 and V4.12](#)
- [Main differences between V4.12 and V4.11](#)
- [Main differences between V4.11 and V4.10](#)
- [Main differences between V4.10 and V4.9](#)
- [Main differences between V4.9 and V4.8](#)
- [Main differences between V4.8 and V4.7](#)
- [Main differences between V4.7 and V4.6.1](#)
- [Main differences between V4.6.1 and V4.5.1](#)
- [Main differences between V4.5.1 and V4.4](#)
- [Main differences between V4.4 and V4.3](#)
- [Main differences between V4.3 and V4.2](#)
- [Main differences between V4.2 and V4.1.1](#)
- [Main differences between V4.1.1 and V4.1](#)
- [Main differences between V4.1 and V4.0](#)
- [Main differences between V4.0 and V3.4.1](#)

User Manual

- [User Manual 4.13](#)
- [User Manual 4.12](#)
- [User Manual 4.11](#)
- [User Manual 4.10](#)
- [User Manual 4.9](#)
- [User Manual 4.8](#)
- [User Manual 4.7](#)
- [User Manual 4.6.1](#)
- [User Manual 4.5.1](#)
- [User Manual 4.4](#)
- [User Manual 4.3](#)
- [User Manual 4.2](#)
- [User Manual 4.1](#)
- [User Manual 4.0](#)

- [User Manual 3.4.1](#)
- [User Manual 3.3](#)

Tutorials

- [Tutorials 4.5.1](#)
- [Tutorials 4.4](#)
- [Tutorials 4.1](#)
- [Tutorials 4.0](#)

Links

- [CNES freeware server](#)

Navigation

- [Accueil](#)
- [Modifications récentes](#)
- [Page au hasard](#)
- [Aide](#)

Outils

- [Pages liées](#)
- [Suivi des pages liées](#)
- [Pages spéciales](#)
- [Adresse de cette version](#)
- [Information sur la page](#)
- [Citer cette page](#)

• Dernière modification de cette page le 2 mars 2018 à 13:32.

- [Politique de confidentialité](#)
- [À propos de Wiki](#)
- [Avertissements](#)
-