

LOFOffsetAttitudeLaw 4.1

De Wiki

Aller à : [navigation](#), [rechercher](#)

[LOFOffsetAttitudeLaw 4.1](#)

```
public class LOFOffsetAttitudeLaw {

    public static void main(String[] args) throws PatriusException {

        // Patrius Dataset initialization (needed for example to get the UTC
time
        PatriusDataset.addResourcesFromPatriusDataset() ;

        // Recovery of the UTC time scale using a "factory" (not to duplicate
such unique object)
        final TimeScale TUC = TimeScalesFactory.getUTC();

        // Date of the orbit given in UTC time scale)
        final AbsoluteDate date = new AbsoluteDate("2010-01-01T12:00:00.000",
TUC);

        // Getting the frame with wich will defined the orbit parameters
// As for time scale, we will use also a "factory".
        final Frame GCRF = FramesFactory.getGCRF();

        // Initial orbit
        final double sma = 7200.e+3;
        final double exc = 0.01;
        final double inc = FastMath.toRadians(98.);
        final double pa = FastMath.toRadians(0.);
        final double raan = FastMath.toRadians(0.);
        final double anm = FastMath.toRadians(0.);
        final double MU = Constants.WGS84_EARTH_MU;

        final KeplerianParameters par = new KeplerianParameters(sma, exc,
inc, pa, raan, anm, PositionAngle.MEAN, MU);
        final Orbit iniOrbit = new KeplerianOrbit(par, GCRF, date);

        // Building a first attitude law
        final AttitudeLaw attitudeLaw0= new LofOffset(LOFType.TNW);
        final Attitude att0 = attitudeLaw0.getAttitude(iniOrbit);

        // Building a second attitude law with a 45 deg rotation on Z axis
        final double psi = FastMath.toRadians(45.);
        final double teta = 0.;
        final double phi = 0.;
        final AttitudeLaw attitudeLaw = new LofOffset(LOFType.TNW,
RotationOrder.ZYX, psi, teta, phi);
        final Attitude att = attitudeLaw.getAttitude(iniOrbit);
```

```
// Rotation of the X axis
Vector3D vec0 = att0.getRotation().applyTo(Vector3D.PLUS_I);
Vector3D vec  = att.getRotation().applyTo(Vector3D.PLUS_I);
double cos = vec.dotProduct(vec0);
double ang = FastMath.acos(cos);
System.out.println(FastMath.toDegrees(ang));

// Rotation of the Y axis
vec0 = att0.getRotation().applyTo(Vector3D.PLUS_J);
vec  = att.getRotation().applyTo(Vector3D.PLUS_J);
cos = vec.dotProduct(vec0);
ang = FastMath.acos(cos);
System.out.println(FastMath.toDegrees(ang));

// Z axis comparison
vec0 = att0.getRotation().applyTo(Vector3D.PLUS_K);
vec  = att.getRotation().applyTo(Vector3D.PLUS_K);
final Vector3D dVec = vec.subtract(vec0);
final double norm = dVec.getNorm();
System.out.println(norm);

}

}
```

Récupérée de « http://patrius.cnes.fr/index.php?title=LOFOffsetAttitudeLaw_4.1&oldid=1826 »

Menu de navigation

Outils personnels

- [3.21.159.223](#)
- [Discussion avec cette adresse IP](#)
- [Créer un compte](#)
- [Se connecter](#)

Espaces de noms

- [Page](#)
- [Discussion](#)

Variantes

Affichages

- [Lire](#)
- [Voir le texte source](#)

- [Historique](#)
- [Exporter en PDF](#)

Plus

Rechercher

PATRIUS

- [Welcome](#)

Evolutions

- [Main differences between V4.15 and V4.14](#)
- [Main differences between V4.14 and V4.13](#)
- [Main differences between V4.13 and V4.12](#)
- [Main differences between V4.12 and V4.11](#)
- [Main differences between V4.11 and V4.10](#)
- [Main differences between V4.10 and V4.9](#)
- [Main differences between V4.9 and V4.8](#)
- [Main differences between V4.8 and V4.7](#)
- [Main differences between V4.7 and V4.6.1](#)
- [Main differences between V4.6.1 and V4.5.1](#)
- [Main differences between V4.5.1 and V4.4](#)
- [Main differences between V4.4 and V4.3](#)
- [Main differences between V4.3 and V4.2](#)
- [Main differences between V4.2 and V4.1.1](#)
- [Main differences between V4.1.1 and V4.1](#)
- [Main differences between V4.1 and V4.0](#)
- [Main differences between V4.0 and V3.4.1](#)

User Manual

- [User Manual 4.15](#)
- [User Manual 4.14](#)
- [User Manual 4.13](#)
- [User Manual 4.12](#)
- [User Manual 4.11](#)
- [User Manual 4.10](#)
- [User Manual 4.9](#)
- [User Manual 4.8](#)
- [User Manual 4.7](#)

- [User Manual 4.6.1](#)
- [User Manual 4.5.1](#)
- [User Manual 4.4](#)
- [User Manual 4.3](#)
- [User Manual 4.2](#)
- [User Manual 4.1](#)
- [User Manual 4.0](#)
- [User Manual 3.4.1](#)
- [User Manual 3.3](#)

Tutorials

- [Tutorials 4.15](#)
- [Tutorials 4.14](#)
- [Tutorials 4.13.5](#)
- [Tutorials 4.12.1](#)
- [Tutorials 4.8.1](#)
- [Tutorials 4.5.1](#)
- [Tutorials 4.4](#)
- [Tutorials 4.1](#)
- [Tutorials 4.0](#)

Links

- [CNES freeware server](#)

Navigation

- [Accueil](#)
- [Modifications récentes](#)
- [Page au hasard](#)
- [Aide](#)

Outils

- [Pages liées](#)
- [Suivi des pages liées](#)
- [Pages spéciales](#)
- [Adresse de cette version](#)
- [Information sur la page](#)
- [Citer cette page](#)

• Dernière modification de cette page le 18 décembre 2018 à 10:17.

- [Politique de confidentialité](#)
- [À propos de Wiki](#)
- [Avertissements](#)

