

ParametersConversions 4.5.1

De Wiki

Aller à : [navigation](#), [rechercher](#)

[ParametersConversions 4.5.1](#)

```
public class ParametersConversions {  
  
    public static void main(String[] args) throws PatriusException,  
IOException, ParseException, URISyntaxException {  
  
        // Patrius Dataset initialization (needed for example to get the UTC  
time)  
        PatriusDataset.addResourcesFromPatriusDataset() ;  
  
        // Constants that will be used for conversions  
        final double REQ  = Constants.WGS84_EARTH_EQUATORIAL_RADIUS;  
        final double MU   = Constants.WGS84_EARTH_MU;  
  
        // Initialization of keplerian parameters  
        final double dga = REQ + 250.e3;  
        final double exc = 0.;  
        final double inc = FastMath.toRadians(45.);  
        final double gom = FastMath.toRadians(10.);  
        final double pom = FastMath.toRadians(0.);  
        final double ano = FastMath.toRadians(180.);  
        final KeplerianParameters kep = new KeplerianParameters(dga, exc,  
inc, pom, gom, ano, PositionAngle.MEAN, MU);  
  
        // Same in circular parameters  
        final CircularParameters cir1 = new CircularParameters(dga,  
exc*FastMath.cos(pom), exc*FastMath.sin(pom),  
                                         inc, gom, pom+ano,  
PositionAngle.MEAN, MU);  
        // Same in circular parameters but coming from conversion  
        final CircularParameters cir2 = kep.getCircularParameters();  
  
        // Display of potential differences  
        System.out.println("TEST CIRCULAR PARAMETERS ...");  
        System.out.println("Delta dga = "+(cir2.getA() - cir1.getA()));  
        System.out.println("Delta ex  = "+(cir2.getCircularEx() -  
cir1.getCircularEx()));  
        System.out.println("Delta ey  = "+(cir2.getCircularEy() -  
cir1.getCircularEy()));  
        System.out.println("Delta inc = "+(cir2.getI() - cir1.getI()));  
        System.out.println("Delta gom =  
"+(cir2.getRightAscensionOfAscendingNode() -  
cir1.getRightAscensionOfAscendingNode()));  
        System.out.println("Delta pso = "+(cir2.getAlpha(PositionAngle.MEAN)  
- cir1.getAlpha(PositionAngle.MEAN)));
```

```

// Same in equatorial parameters
final EquatorialParameters equ1 = new EquatorialParameters(dga, exc,
pom+gom,
    2.*FastMath.sin(inc/2.)*FastMath.cos(gom),
2.*FastMath.sin(inc/2.)*FastMath.sin(gom), ano, PositionAngle.MEAN, MU);
// Same in equatorial parameters but coming from conversion
final EquatorialParameters equ2 = kep.getEquatorialParameters();

// Display of potential differences
System.out.println("TEST EQUATORIAL PARAMETERS ...");
System.out.println("Delta dga = "+(equ2.getA() - equ1.getA()));
System.out.println("Delta exc = "+(equ2.getE() - equ1.getE()));
System.out.println("Delta pom = "+(equ2.getPomega() -
equ1.getPomega()));
System.out.println("Delta ix  = "+(equ2.getIx() - equ1.getIx()));
System.out.println("Delta iy  = "+(equ2.getIy() - equ1.getIy()));
System.out.println("Delta ano =
"+(equ2.getAnomaly(PositionAngle.MEAN) -
equ1.getAnomaly(PositionAngle.MEAN)));

// Same in equinoctial parameters
final EquinoctialParameters eqx1 = new EquinoctialParameters(dga,
exc*FastMath.cos(pom+gom), exc*FastMath.sin(pom+gom),
    FastMath.tan(inc/2.)*FastMath.cos(gom),
FastMath.tan(inc/2.)*FastMath.sin(gom), ano+pom+gom, PositionAngle.MEAN, MU);
// Same in equinoctial parameters but coming from conversion
final EquinoctialParameters eqx2 = kep.getEquinoctialParameters();

// Display of potential differences
System.out.println("TEST EQUINOCTIAL PARAMETERS ...");
System.out.println("Delta dga = "+(eqx2.getA() - eqx1.getA()));
System.out.println("Delta ex  = "+(eqx2.getEquinoctialEx() -
eqx1.getEquinoctialEx()));
System.out.println("Delta ey  = "+(eqx2.getEquinoctialEy() -
eqx1.getEquinoctialEy()));
System.out.println("Delta hx  = "+(eqx2.getHx() - eqx1.getHx()));
System.out.println("Delta hy  = "+(eqx2.getHy() - eqx1.getHy()));
System.out.println("Delta lon = "+(eqx2.getL(PositionAngle.MEAN) -
eqx1.getL(PositionAngle.MEAN)));

final double rpe = dga*(1.-exc);
final double rap = dga*(1.+exc);

// Same in apsis radius parameters
final ApsisRadiusParameters apr1 = new ApsisRadiusParameters(rpe,
rap, inc, pom, gom, ano, PositionAngle.MEAN, MU);
// Same in apsis radius parameters but coming from conversion
final ApsisRadiusParameters apr2 = kep.getApsisRadiusParameters();

// Display of potential differences

```

```

        System.out.println("TEST APSIS RADIUS PARAMETERS ...");
        System.out.println("Delta rpe = "+(apr2.getPeriapsis() -
apr1.getPeriapsis()));
        System.out.println("Delta rap = "+(apr2.getApoapsis() -
apr1.getApoapsis()));
        System.out.println("Delta inc = "+(apr2.getI() - apr1.getI()));
        System.out.println("Delta pom = "+(apr2.getPerigeeArgument() -
apr1.getPerigeeArgument()));
        System.out.println("Delta gom =
"+(apr2.getRightAscensionOfAscendingNode() -
apr1.getRightAscensionOfAscendingNode()));
        System.out.println("Delta ano =
"+(apr2.getAnomaly(PositionAngle.MEAN) -
apr1.getAnomaly(PositionAngle.MEAN)));

        // Same in apsis altitude
        final ApsisAltitudeParameters apa1 = new
ApsisAltitudeParameters(rpe-REQ, rap-REQ, inc, pom, gom, ano,
PositionAngle.MEAN, MU, REQ);
        // Same in apsis altitude parameters but coming from conversion
        final ApsisAltitudeParameters apa2 =
kep.getApsisAltitudeParameters(REQ);

        // Display of potential differences
        System.out.println("TEST APSIS ALTITUDE PARAMETERS ...");
        System.out.println("Delta hpe = "+(apa2.getPeriapsisAltitude() -
apa1.getPeriapsisAltitude()));
        System.out.println("Delta hap = "+(apa2.getApoapsisAltitude() -
apa1.getApoapsisAltitude()));
        System.out.println("Delta inc = "+(apa2.getI() - apa1.getI()));
        System.out.println("Delta pom = "+(apa2.getPerigeeArgument() -
apa1.getPerigeeArgument()));
        System.out.println("Delta gom =
"+(apa2.getRightAscensionOfAscendingNode() -
apa1.getRightAscensionOfAscendingNode()));
        System.out.println("Delta ano =
"+(apa2.getAnomaly(PositionAngle.MEAN) -
apa1.getAnomaly(PositionAngle.MEAN)));

    }

}

```

Récupérée de « http://patrius.cnrs.fr/index.php?title=ParametersConversions_4.5.1&oldid=2688 »

Menu de navigation

Outils personnels

- 18.222.164.176

- [Discussion avec cette adresse IP](#)
- [Créer un compte](#)
- [Se connecter](#)

Espaces de noms

- [Page](#)
- [Discussion](#)

Variantes

Affichages

- [Lire](#)
- [Voir le texte source](#)
- [Historique](#)
- [Exporter en PDF](#)

Plus

Rechercher

PATRIUS

- [Welcome](#)

Evolutions

- [Main differences between V4.15 and V4.14](#)
- [Main differences between V4.14 and V4.13](#)
- [Main differences between V4.13 and V4.12](#)
- [Main differences between V4.12 and V4.11](#)
- [Main differences between V4.11 and V4.10](#)
- [Main differences between V4.10 and V4.9](#)
- [Main differences between V4.9 and V4.8](#)
- [Main differences between V4.8 and V4.7](#)
- [Main differences between V4.7 and V4.6.1](#)
- [Main differences between V4.6.1 and V4.5.1](#)
- [Main differences between V4.5.1 and V4.4](#)
- [Main differences between V4.4 and V4.3](#)

- [Main differences between V4.3 and V4.2](#)
- [Main differences between V4.2 and V4.1.1](#)
- [Main differences between V4.1.1 and V4.1](#)
- [Main differences between V4.1 and V4.0](#)
- [Main differences between V4.0 and V3.4.1](#)

User Manual

- [User Manual 4.15](#)
- [User Manual 4.14](#)
- [User Manual 4.13](#)
- [User Manual 4.12](#)
- [User Manual 4.11](#)
- [User Manual 4.10](#)
- [User Manual 4.9](#)
- [User Manual 4.8](#)
- [User Manual 4.7](#)
- [User Manual 4.6.1](#)
- [User Manual 4.5.1](#)
- [User Manual 4.4](#)
- [User Manual 4.3](#)
- [User Manual 4.2](#)
- [User Manual 4.1](#)
- [User Manual 4.0](#)
- [User Manual 3.4.1](#)
- [User Manual 3.3](#)

Tutorials

- [Tutorials 4.15](#)
- [Tutorials 4.14](#)
- [Tutorials 4.13.5](#)
- [Tutorials 4.12.1](#)
- [Tutorials 4.8.1](#)
- [Tutorials 4.5.1](#)
- [Tutorials 4.4](#)
- [Tutorials 4.1](#)
- [Tutorials 4.0](#)

Links

- [CNES freeware server](#)

Navigation

- [Accueil](#)
- [Modifications récentes](#)

- [Page au hasard](#)
- [Aide](#)

Outils

- [Pages liées](#)
- [Suivi des pages liées](#)
- [Pages spéciales](#)
- [Adresse de cette version](#)
- [Information sur la page](#)
- [Citer cette page](#)

• Dernière modification de cette page le 17 août 2020 à 09:01.

- [Politique de confidentialité](#)
- [À propos de Wiki](#)
- [Avertissements](#)
-