

# User Manual 4.0 Properties and models: Inertia

De Wiki

Aller à : [navigation](#), [rechercher](#)

[User Manual 4.0 Properties and models: Inertia](#)

## Sommaire

- [1 Introduction](#)
  - [1.1 Scope](#)
  - [1.2 Javadoc](#)
  - [1.3 Links](#)
  - [1.4 Useful Documents](#)
  - [1.5 Package Overview](#)
- [2 Features Description](#)
  - [2.1 Generalities about inertia models](#)
  - [2.2 Simple inertia model](#)
  - [2.3 Computed inertia model](#)
  - [2.4 Inertia properties](#)
- [3 Getting Started](#)
- [4 Contents](#)
  - [4.1 Interfaces](#)
  - [4.2 Classes](#)

## Introduction

### Scope

In this sections are presented the assembly's properties and models to get its inertia features : mass, mass center and inertia matrix.

### Javadoc

The inertia models are available in the package [fr.cnes.sirius.patrius.assembly.models](#).

The associated properties are available in the package [fr.cnes.sirius.patrius.assembly.properties](#).

### Links

None as of now.

### Useful Documents

None as of now.

## Package Overview

None as of now.

## Features Description

### Generalities about inertia models

The aim of inertia models is to return the (mass / center of mass / inertia matrix) information for the whole spacecraft. Two models are available : one that allows the user to fill directly those informations, one that computes it from the inertia of the different parts of the assembly.

Those models are under the "IInertiaModel" interface, that defines the following methods :

- Getter for the inertia matrix of the spacecraft, expressed with respect to the MASS CENTER in a given frame.

```
Matrix3D inertiaMatrixAtMassCenter = model.getInertiaMatrix(frame, date);
```

- Getter for the inertia matrix of the spacecraft, once expressed with respect to a point (expressed in the given frame) that can be different from the mass center.

```
Matrix3D matrix = model.getInertiaMatrix(frame, date, inertiaReferencePoint);
```

- getter for the mass center in a given frame

```
Vector3D massCenterInUserFrame = model.getMassCenter(frame, date);
```

- getter for the last computed mass

```
double globalMass = model.getTotalMass();
```

### Simple inertia model

In the InertiaSimpleModel, the mass / mass center / inertia matrix are directly provided by the user. It does not need any assembly construction.

The inertia matrix can be defined :

- at the mass center point, in a given reference frame, with the following constructor

```
IInertiaModel model = new InertiaSimpleModel(mass, massCenter, inertiaMatrix, referenceFrame, "part");
```

- at another point, in a given reference frame, with the following constructor

```
IInertiaModel model = new InertiaSimpleModel(mass, massCenter, inertiaMatrix, inertiaReferencePoint, referenceFrame, "part");
```

## Computed inertia model

The `InertiaComputedModel` computes those values from the part properties of an assembly. The concerned parts are the ones containing the `INERTIA` properties (cf. next paragraph).

It is built simply from the assembly :

```
IIInertiaModel model = new InertiaComputedModel(assembly);
```

## Inertia properties

The `INERTIA` property completes the `MASS` property to get a complete (mass / center of mass / inertia matrix) description of a part. It shall be built providing the mass property that is associated to the same part (so both properties will provide and work with the same mass value even if it changes in time). Consequently, the property contains three informations :

- the mass value (get from the `MASS` property itself)
- the mass-center vector
- the inertia matrix at the mass center point

There are different ways to define it : computing it from a geometry (sphere, box...), or giving it directly. So many classes are available, implementing the same interface. The `IIInertiaProperty` interface and `AbstractInertiaProperty` are the interface and abstract class for all the different Inertia properties available and shall be used by users willing to create their own inertia definition of the part.

Check the different javadocs for the building of those properties.



The property type associated is **INERTIA**.

Here are the different geometrical pre-computed available inertia:

### Sphere

Defined by its radius. The `CENTER` of the sphere is the (0, 0, 0) point of the part frame of this property.



### Parallelepiped

Defined by its length (dimension on the X axis of the part frame of the property), width (dimension on the Y axis of this frame) and height (on the Z axis). The `CENTER` of the parallelepiped is the (0, 0, 0) point.



### Cylinder

Defined by the radius of its base and height. The (0, 0, 0) point of the part frame of this property is the center of a base, the axis on the positive Z axis.



## Getting Started

Here is a code sample for the creation of an inertia property associated to the part "part1" :

```
// mass property creation for this part
final MassProperty massProp = new MassProperty(55.0);

// mass property adding
assemblyBuilder.addProperty(massProp, "part1");

// inertia features : mass center
Vector3D massCenter = new Vector3D( 0.0, 0.7849, 0.0016);

// inertia features : inertia matrix at mass center
final double[][] inertiaData = {{9.2814945, 0. , 0. },
                                {0., 0.1422165, - 0.0160876},
                                {0., - 0.0160876, 9.148478 }};
final Matrix3D inertiaMatrix = new Matrix3D(inertiaData);

// inertia property creation : the mass property is the one given to the same
part
final InertiaSimpleProperty inertiaProp = new
InertiaSimpleProperty(massCenter, inertiaMatrix, massProp);

// inertia property adding
assemblyBuilder.addProperty(inertiaProp, "part1");
```

## Contents

### Interfaces

Interface	Summary	Javadoc
<b>IInertiaModel</b>	Interface for inertia models.	<a href="#">...</a>
<b>IInertiaProperty</b>	Interface for all inertia parts properties.	<a href="#">...</a>

### Classes

Class	Summary	Javadoc
<b>InertiaSimpleModel</b>	This class is a model to describe a construction's inertia : it does not need an assembly.	<a href="#">...</a>
<b>InertiaComputedModel</b>	This class is a model to describe an assembly's inertia.	<a href="#">...</a>
<b>InertiaSimpleProperty</b>	This class is a part property for the PATRIUS assembly. It allows to define an inertia property to a part, the mass center and inertia matrix at the mass center being provided by the user.	<a href="#">...</a>

<b>InertiaSphereProperty</b>	This class is a part property for the PATRIUS assembly. It allows to define an inertia property to a part, the mass center and inertia matrix being computed for a spherical object. <span style="float: right;">...</span>
<b>InertiaParallelepipedProperty</b>	This class is a part property for the PATRIUS assembly. It allows to define an inertia property to a part, the mass center and inertia matrix being computed for a parallelepiped object. <span style="float: right;">...</span>
<b>InertiaCylinderProperty</b>	This class is a part property for the PATRIUS assembly. It allows to define an inertia property to a part, the mass center and inertia matrix being computed for a cylinder object. <span style="float: right;">...</span>

Récupérée de

«

[http://patrius.cnes.fr/index.php?title=User\\_Manual\\_4.0\\_Properties\\_and\\_models:\\_Inertia&oldid=828](http://patrius.cnes.fr/index.php?title=User_Manual_4.0_Properties_and_models:_Inertia&oldid=828)

»

Catégorie :

- [User Manual 4.0 Spacecraft](#)

## Menu de navigation

### Outils personnels

- [3.135.205.231](#)
- [Discussion avec cette adresse IP](#)
- [Créer un compte](#)
- [Se connecter](#)

### Espaces de noms

- [Page](#)
- [Discussion](#)

### Variantes

### Affichages

- [Lire](#)
- [Voir le texte source](#)
- [Historique](#)
- [Exporter en PDF](#)

### Plus

## Rechercher

## PATRIUS

- [Welcome](#)

## Evolutions

- [Main differences between V4.15 and V4.14](#)
- [Main differences between V4.14 and V4.13](#)
- [Main differences between V4.13 and V4.12](#)
- [Main differences between V4.12 and V4.11](#)
- [Main differences between V4.11 and V4.10](#)
- [Main differences between V4.10 and V4.9](#)
- [Main differences between V4.9 and V4.8](#)
- [Main differences between V4.8 and V4.7](#)
- [Main differences between V4.7 and V4.6.1](#)
- [Main differences between V4.6.1 and V4.5.1](#)
- [Main differences between V4.5.1 and V4.4](#)
- [Main differences between V4.4 and V4.3](#)
- [Main differences between V4.3 and V4.2](#)
- [Main differences between V4.2 and V4.1.1](#)
- [Main differences between V4.1.1 and V4.1](#)
- [Main differences between V4.1 and V4.0](#)
- [Main differences between V4.0 and V3.4.1](#)

## User Manual

- [User Manual 4.15](#)
- [User Manual 4.14](#)
- [User Manual 4.13](#)
- [User Manual 4.12](#)
- [User Manual 4.11](#)
- [User Manual 4.10](#)
- [User Manual 4.9](#)
- [User Manual 4.8](#)
- [User Manual 4.7](#)
- [User Manual 4.6.1](#)
- [User Manual 4.5.1](#)
- [User Manual 4.4](#)
- [User Manual 4.3](#)
- [User Manual 4.2](#)
- [User Manual 4.1](#)
- [User Manual 4.0](#)

- [User Manual 3.4.1](#)
- [User Manual 3.3](#)

## Tutorials

- [Tutorials 4.15](#)
- [Tutorials 4.14](#)
- [Tutorials 4.13.5](#)
- [Tutorials 4.12.1](#)
- [Tutorials 4.8.1](#)
- [Tutorials 4.5.1](#)
- [Tutorials 4.4](#)
- [Tutorials 4.1](#)
- [Tutorials 4.0](#)

## Links

- [CNES freeware server](#)

## Navigation

- [Accueil](#)
- [Modifications récentes](#)
- [Page au hasard](#)
- [Aide](#)

## Outils

- [Pages liées](#)
- [Suivi des pages liées](#)
- [Pages spéciales](#)
- [Adresse de cette version](#)
- [Information sur la page](#)
- [Citer cette page](#)
  
- Dernière modification de cette page le 21 février 2018 à 14:26.
- [Politique de confidentialité](#)
- [À propos de Wiki](#)
- [Avertissements](#)
- 