

User Manual 4.15 SpacecraftState

De Wiki

Aller à : [navigation](#), [rechercher](#)

[User Manual 4.15 SpacecraftState](#)

Introduction

Scope

This section describes the SpacecraftState object.

Javadoc

The object [\[\[\[:Modèle:JavaDoc4.15\]\]/fr/cnes/sirius/patrius/propagation/SpacecraftState.html SpacecraftState\]](#) is available in the package `fr.cnes.sirius.patrius.propagation`.

Links

Here is only described the SpacecraftState structure. Please refer to [\[ORB_PRO_Home propagation chapter\]](#).

Useful Documents

None as of now.

Overview

The [\[\[\[:Modèle:JavaDoc4.15\]\]/fr/cnes/sirius/patrius/propagation/SpacecraftState.html SpacecraftState\]](#) is composed of :

- an [\[\[\[:Modèle:JavaDoc4.15\]\]/fr/cnes/sirius/patrius/orbits/Orbit.html orbit\]](#)
- an [\[\[\[:Modèle:JavaDoc4.15\]\]/fr/cnes/sirius/patrius/attitudes/Attitude.html attitude for forces computation\]](#)
- an [\[\[\[:Modèle:JavaDoc4.15\]\]/fr/cnes/sirius/patrius/attitudes/Attitude.html attitude for events computation\]](#)
- a map of additional states (including mass states added from [\[\[\[:Modèle:JavaDoc4.15\]\]/fr/cnes/sirius/patrius/propagation/MassProvider.html MassProvider\]](#)).

Two attitudes are stored in order to apply (if needed) a different treatment to each attitude.

Features Description

One orbit

The [\[\[\[:Modèle:JavaDoc4.15\]\]/fr/cnes/sirius/patrius/propagation/SpacecraftState.html SpacecraftState\]](#) is composed of one [\[\[\[:Modèle:JavaDoc4.15\]\]/fr/cnes/sirius/patrius/orbits/Orbit.html Orbit\]](#). It is possible to simply declare a SpacecraftState with an orbit :

```
final SpacecraftState state = new SpacecraftState(orbit);
```

The orbit could be updated using the following method : `final SpacecraftState newState = state.updateOrbit(newOrbit);` The attitude and additional states will remain the same and a new `SpacecraftState` will be created.

Two attitudes

The user can use one single

[\[\[\[:Modèle:JavaDoc4.15\]\]/fr/cnes/sirius/patrius/attitudes/Attitude.html Attitude\]](#) or two different [\[\[\[:Modèle:JavaDoc4.15\]\]/fr/cnes/sirius/patrius/attitudes/Attitude.html Attitude\]](#) objects : one for forces computation and one for events computation. The following constructor can be used :

```
final SpacecraftState state = new SpacecraftState(orbit, attitudeForces, attitudeEvents);
```

It is possible to get the attitude for forces or events computation using the following methods:

```
final Attitude attForces = state.getAttitudeForces();
final Attitude attEvents = state.getAttitudeEvents();
```

The user can deal with a single attitude in the `SpacecraftState` using the following constructor:

```
final SpacecraftState state = new SpacecraftState(orbit, attitude);
final Attitude att = state.getAttitude();
```

If the following constructor is used, both attitudes are set to null value: `final SpacecraftState state = new SpacecraftState(orbit);` Then calling `getAttitude` or `getAttitudeForces` or `getAttitudeEvents` will return null attitude.

Additional states

The additional states are stored in the `SpacecraftState` using a `Map` with the additional states names as keys. The additional states are in the type `double[]`. The additional states map could be given directly to the constructor as follow :

```
Map<String, double[]> addStates = new HashMap<String, double[]>();
addStates.put("name", new double[]{1.0});
SpacecraftState state = new SpacecraftState(orbit, attitudeForces, attitudeEvents, addStates);
```

It is possible to add an additional state to a `SpacecraftState` using ***addAdditionalState***:

```
state2 = state.addAdditionalState("name2", new double[]{0.1, 0.1});
```

Note : ***addAdditionalState*** returns a new `SpacecraftState` with the added additional state. It is necessary to store the returned object. The additional state is not added to the current state.

Mass

A [\[\[\[:Modèle:JavaDoc4.15\]\]/fr/cnes/sirius/patrius/propagation/MassProvider.html MassProvider](#)] can be provided to the `SpacecraftState`. In that case, the mass information are automatically stored as additional states. Be careful, the mass values can never be negative:

```
final SpacecraftState state = new SpacecraftState(orbit, massProvider);
final SpacecraftState state = new SpacecraftState(orbit, attitudeForces,
attitudeEvents, massProvider, addStates);
```

The mass provider can be added to the `SpacecraftState` after its initialisation with the method `addMassProvider` :

```
final SpacecraftState state = new SpacecraftState(orbit);
final SpacecraftState newState = state.addMassProvider(massProvider);
```

The mass parts from `MassProvider` are added to additional states map with the key : `"MASS_<partName>"`.

The total mass of the `SpacecraftState` could not be obtained.

It is possible to obtain the mass of a given part : `state.getMass("part1");`

and to update the mass of a given part : `state.updateMass("part1", 1000.0);`

State vector

The [\[\[\[:Modèle:JavaDoc4.15\]\]/fr/cnes/sirius/patrius/propagation/SpacecraftState.html SpacecraftState](#)] object could be created from a state vector : `final SpacecraftState state = new SpacecraftState(stateVector, OrbitType.CARTESIAN, PositionAngle.MEAN, date, mu, frame, addStatesInfo, attProviderForces, attProviderEvents);`

To build the `SpacecraftState`, it is necessary to know the size and the index of all additional states in the state vector. This information could be obtained from an old state using the following method :

```
final Map<String, AdditionalStateInfo> addStatesInfos =
state.getAdditionalStatesInfos();
```

The state vector could be obtained from a `SpacecraftState` :

```
final double[] stateVector = new double[]{};
state.mapStateToArray(OrbitType.CARTESIAN, PositionAngle.MEAN, stateVector);
```

Transform

The [\[\[\[:Modèle:JavaDoc4.15\]\]/fr/cnes/sirius/patrius/propagation/SpacecraftState.html SpacecraftState](#)] class contains methods to compute the following transformations : - `toTransform()` or `toTransformForces()` : Transform from orbit/attitude reference frame to spacecraft frame (attitude used for forces computation which is the default attitude).

- `toTransformEvents()` : Transform from orbit/attitude reference frame to spacecraft frame attitude used for events computation (same as `toTransform` if there is no specific attitude for Events).
- `toTransform(Frame)` or `toTransformForces(Frame)` : Transform from specified [\[\[\[:Modèle:JavaDoc4.15\]\]/fr/cnes/sirius/patrius/frames/Frame.html Frame\]](#) to spacecraft frame (attitude used for forces computation which is the default attitude).
- `toTransformEvents(Frame)` : Transform from specified [\[\[\[:Modèle:JavaDoc4.15\]\]/fr/cnes/sirius/patrius/frames/Frame.html Frame\]](#) to spacecraft frame attitude used for events computation (same as `toTransform(Frame)` if there is no attitude specific for Events).
- `toTransform(LOFType)` : Transform from orbit/attitude reference frame to local orbital frame ([\[\[\[:Modèle:JavaDoc4.15\]\]/fr/cnes/sirius/patrius/frames/LOFType.html LOFType\]](#)).
- `toTransform(Frame, LOFType)` : Transform from specified [\[\[\[:Modèle:JavaDoc4.15\]\]/fr/cnes/sirius/patrius/frames/Frame.html Frame\]](#) to local orbital frame ([\[\[\[:Modèle:JavaDoc4.15\]\]/fr/cnes/sirius/patrius/frames/LOFType.html LOFType\]](#)).

Getting Started

Using Transform

Here after is presented the computation of a station position in spacecraft frame:

```
// Station position defined in GCRF
final Vector3D station_InGCRF = new
Vector3D(Constants.EGM96_EARTH_EQUATORIAL_RADIUS, 0, 0);
final Frame gcrf = FramesFactory.getGCRF();
// Compute transform from GCRF to spacecraft frame
final Transform transform = state.toTransform(gcrf);
// Station position in spacecraft frame
final Vector3D station_InSpacecraftFrame =
transform.transformVector(station_InGCRF);
```

Here after is presented the computation of the Sun direction in spacecraft frame.

```
// Compute transform from orbit/attitude reference frame to local orbital
frame TNW
final Transform transform = state.toTransform(LOFType.TNW);
// Position of Sun in local orbital frame TNW
final Vector3D pos =
transform.transformPosition(sun.getPVCoordinates().getPosition());
```

If an [\[\[\[:Modèle:JavaDoc4.15\]\]/fr/cnes/sirius/patrius/assembly/Assembly.html Assembly\]](#) is used, this is not necessary to use these methods because the conversion methods are included in Assembly functionalities (see [\[SPC_VBU_Home dedicated User Manual\]](#)).

Contents

Interfaces

Interface	Summary	Javadoc
MassProvider	Interface providing the mass for spacecraft models.	[[[:Modèle:JavaDoc4.15]]/fr/cnes/sirius/patrius/propagation/MassProvider.html ...]

Classes

Class	Summary	Javadoc
SpacecraftState	This class is the representation of a complete state holding orbit, attitude for forces and for events computation and additional states at a given date.	[[[:Modèle:JavaDoc4.15]]/fr/cnes/sirius/patrius/propagation/SpacecraftState.html ...]
Attitude	Object representing the attitude of the spacecraft for a specific date and in a specific frame.	[[[:Modèle:JavaDoc4.15]]/fr/cnes/sirius/patrius/attitudes/Attitude.html ...]

Récupérée de

« http://patrius.cnes.fr/index.php?title=User_Manual_4.15_SpacecraftState&oldid=3856 »

Catégorie :

- [User Manual 4.15 Flight Dynamics](#)

Menu de navigation

Outils personnels

- [18.188.91.223](#)
- [Discussion avec cette adresse IP](#)
- [Créer un compte](#)
- [Se connecter](#)

Espaces de noms

- [Page](#)
- [Discussion](#)

Variantes

Affichages

- [Lire](#)
- [Voir le texte source](#)
- [Historique](#)
- [Exporter en PDF](#)

Plus

Rechercher

PATRIUS

- [Welcome](#)

Evolutions

- [Main differences between V4.15 and V4.14](#)
- [Main differences between V4.14 and V4.13](#)
- [Main differences between V4.13 and V4.12](#)
- [Main differences between V4.12 and V4.11](#)
- [Main differences between V4.11 and V4.10](#)
- [Main differences between V4.10 and V4.9](#)
- [Main differences between V4.9 and V4.8](#)
- [Main differences between V4.8 and V4.7](#)
- [Main differences between V4.7 and V4.6.1](#)
- [Main differences between V4.6.1 and V4.5.1](#)
- [Main differences between V4.5.1 and V4.4](#)
- [Main differences between V4.4 and V4.3](#)
- [Main differences between V4.3 and V4.2](#)
- [Main differences between V4.2 and V4.1.1](#)
- [Main differences between V4.1.1 and V4.1](#)
- [Main differences between V4.1 and V4.0](#)
- [Main differences between V4.0 and V3.4.1](#)

User Manual

- [User Manual 4.15](#)
- [User Manual 4.14](#)
- [User Manual 4.13](#)
- [User Manual 4.12](#)
- [User Manual 4.11](#)

- [User Manual 4.10](#)
- [User Manual 4.9](#)
- [User Manual 4.8](#)
- [User Manual 4.7](#)
- [User Manual 4.6.1](#)
- [User Manual 4.5.1](#)
- [User Manual 4.4](#)
- [User Manual 4.3](#)
- [User Manual 4.2](#)
- [User Manual 4.1](#)
- [User Manual 4.0](#)
- [User Manual 3.4.1](#)
- [User Manual 3.3](#)

Tutorials

- [Tutorials 4.15](#)
- [Tutorials 4.14](#)
- [Tutorials 4.13.5](#)
- [Tutorials 4.12.1](#)
- [Tutorials 4.8.1](#)
- [Tutorials 4.5.1](#)
- [Tutorials 4.4](#)
- [Tutorials 4.1](#)
- [Tutorials 4.0](#)

Links

- [CNES freeware server](#)

Navigation

- [Accueil](#)
- [Modifications récentes](#)
- [Page au hasard](#)
- [Aide](#)

Outils

- [Pages liées](#)
- [Suivi des pages liées](#)
- [Pages spéciales](#)
- [Adresse de cette version](#)
- [Information sur la page](#)
- [Citer cette page](#)

• Dernière modification de cette page le 21 novembre 2024 à 15:30.

- [Politique de confidentialité](#)
- [À propos de Wiki](#)
- [Avertissements](#)
- 